

Second-Order Models in RSM

When the curvature is detected, the experimenter is relatively close to the optimum, so a model that incorporates curvature is usually required to approximate the response.

$$y = \beta_0 + \sum_{i=1}^k \beta_i x_i + \sum_{i=1}^k \beta_{ii} x_i^2 + \sum_{i < j} \beta_{ij} x_i x_j + \varepsilon$$

- Second-order models are used widely in practice
- The Taylor series analogy
- Optimization is easy
- There is a lot of empirical evidence that they work very well


Stationary Point

- Suppose we wish to find the levels of $x_1, x_2, \dots, x_k$ that optimize the predicted response.
- This point, if it exists, may be the set of $x_1, x_2, \dots, x_k$ for which the partial derivatives

$$\partial \hat{y} / \partial x_1 = \partial \hat{y} / \partial x_2 = \dots = \partial \hat{y} / \partial x_k = 0$$


- This point is called the stationary point.
- Stationary point represents...
 - Maximum Point
 - Minimum Point
 - Saddle Point

Maximum Response




■ FIGURE 11.6 Response surface and contour plot illustrating a surface with a maximum

Minimum Response



■ **FIGURE 11.7** Response surface and contour plot illustrating a surface with a minimum

Saddle Point



■ FIGURE 11.8 Response surface and contour plot illustrating a saddle point (or minimax)

Finding the Stationary Point

After fitting a second order model

$$\hat{y} = \hat{\beta}_0 + \sum \hat{\beta}_i x_i + \sum \hat{\beta}_{ii} x_i^2 + \sum \sum \hat{\beta}_{ij} x_i x_j$$

take the partial derivatives with respect to the x_i 's and set to zero

$$\partial \hat{y} / \partial x_1 = \partial \hat{y} / \partial x_2 = \cdots = \partial \hat{y} / \partial x_k = 0$$

Finding the Stationary Point

Matrix view

$$\hat{y} = \hat{\beta}_0 + \mathbf{x}'\mathbf{b} + \mathbf{x}'\mathbf{B}\mathbf{x}$$

$$\mathbf{x} = \begin{bmatrix} x_1 \\ x_2 \\ \vdots \\ x_k \end{bmatrix} \quad \mathbf{b} = \begin{bmatrix} \hat{\beta}_1 \\ \hat{\beta}_2 \\ \vdots \\ \hat{\beta}_k \end{bmatrix} \quad \text{and} \quad \mathbf{B} = \begin{bmatrix} \hat{\beta}_{11}, & \hat{\beta}_{12}/2, & \dots, & \hat{\beta}_{1k}/2 \\ & \hat{\beta}_{22}, & \dots, & \hat{\beta}_{2k}/2 \\ & & \ddots & \\ \text{sym.} & & & \hat{\beta}_{kk} \end{bmatrix}$$

$$\frac{\partial \hat{y}}{\partial \mathbf{x}} = \mathbf{b} + 2\mathbf{B}\mathbf{x} = \mathbf{0}$$

$$\mathbf{x}_s = -\frac{1}{2}\mathbf{B}^{-1}\mathbf{b}$$


Characterization of the Response Surface

- After we have found the stationary point
- Find what type of surface we have
 - Graphical Analysis: contour plot
 - Canonical Analysis
- Determine the sensitivity of the response variable to the optimum value
 - Canonical Analysis

Canonical Analysis

- Transform the model into a new coordinate system
- Origin at the stationary point
- Rotate the axes of this system until they are parallel to the principal axes of the fitted response surface.
- The model in the new system is

$$\hat{y} = \hat{y}_s + \lambda_1 w_1^2 + \lambda_2 w_2^2 + \cdots + \lambda_k w_k^2$$



the $\{\lambda_i\}$ are just the **eigenvalues** of the matrix **B**

$$\mathbf{B} = \begin{bmatrix} \hat{\beta}_{11}, & \hat{\beta}_{12}/2, & \dots, & \hat{\beta}_{1k}/2 \\ & \hat{\beta}_{22}, & \dots, & \hat{\beta}_{2k}/2 \\ & & \ddots & \\ \text{sym.} & & & \hat{\beta}_{kk} \end{bmatrix}$$

Steps of Canonical Analysis:

1. From the model

$$\hat{y} = \hat{\beta}_0 + \sum \hat{\beta}_i x_i + \sum \hat{\beta}_{ii} x_i^2 + \sum \sum \hat{\beta}_{ij} x_i x_j$$

we have matrix **B**.

2. Obtain the stationary point x_s .

3. Compute the eigenvalues of B, denoted as $\{\lambda_i\}$, we have the canonical model

$$\hat{y} = \hat{y}_s + \lambda_1 w_1^2 + \lambda_2 w_2^2 + \cdots + \lambda_k w_k^2$$

4. The nature of the response can be determined by the signs and magnitudes of the eigenvalues $\{\lambda_i\}$

- all positive: a minimum is found
- all negative: a maximum is found
- mixed: a saddle point is found
- The response surface is steepest (most sensitive) in the direction (canonical) corresponding to the largest absolute eigenvalue

Return to the example:

- Obtain stationary point

$$\mathbf{b} = \begin{bmatrix} 0.995 \\ 0.515 \end{bmatrix} \quad \mathbf{B} = \begin{bmatrix} -1.376 & 0.1250 \\ 0.1250 & -1.001 \end{bmatrix}$$

$$\begin{aligned} \mathbf{x}_s &= -\frac{1}{2}\mathbf{B}^{-1}\mathbf{b} \\ &= -\frac{1}{2} \begin{bmatrix} -0.7345 & -0.0917 \\ -0.0917 & -1.0096 \end{bmatrix} \begin{bmatrix} 0.995 \\ 0.515 \end{bmatrix} = \begin{bmatrix} 0.389 \\ 0.306 \end{bmatrix} \end{aligned}$$

In terms of the natural variables, the stationary point is

$$0.389 = \frac{\xi_1 - 85}{5} \quad 0.306 = \frac{\xi_1 - 175}{5}$$

$$\xi_1 = 86.95 \quad \xi_2 = 176.53$$


- Compute eigenvalues of B

$$\begin{aligned}
 |\mathbf{B} - \lambda \mathbf{I}| &= 0 \\
 \begin{vmatrix} -1.376 - \lambda & 0.1250 \\ 0.1250 & -1.001 - \lambda \end{vmatrix} &= 0 \\
 \lambda^2 + 2.3788\lambda + 1.3639 &= 0 \\
 \lambda_1 = -0.9634 \text{ and } \lambda_2 = -1.4141
 \end{aligned}$$


Thus, the canonical form of the fitted model is

$$\hat{y} = 80.21 - 0.9634w_1^2 - 1.4141w_2^2$$

Because both λ_1 and λ_2 are negative and the stationary point is within the region of exploration, we conclude that the stationary point is a maximum.



(a) The contour plot



(b) The response surface plot

■ **FIGURE 11.11** Contour and response surface plots of the yield response, Example 11.2